

INSTRUCTION SHEET

How to Apply Vinyl Decals to Glass Surface (Wet Application)

(A) YOUR DECAL



Your decal comes in 3 layers - transfer tape, vinyl decal and backing paper.

(B) GET READY THESE TOOLS



1. Spray Bottle of Application Fluid - mix half teaspoon of soap with 250ml water



2. Lint-free Cloth



3. Squeegee / a Hard Card e.g. Credit Card



4. Masking Tape

(C) PREPARING YOUR DECAL AND SURFACE



1. Remove decal from the tube and unroll decal on a flat surface. Flip over and rub surface of backing paper with squeegee/hard card. This breaks the bond of the graphics from the backing paper, so that the graphics are not stuck to the backing paper.



2. For decals that need assembling, cut and separate the different elements.



3. Clean the glass so it's free from dust and dirt. Avoid soap that contains cream, lotion, silicones or ammonia, which interfere with adhesiveness.

(D) APPLYING YOUR DECAL



1. Measure and mark the position of your decal with masking tapes. Use the actual decal as a guide, NOT the edge of the transfer tape or backing paper.



2. Carefully remove the backing paper. If decal sticks to the backing, press back, rub a little and try again. OR try peeling from another direction. Avoid touching the adhesive on the vinyl decal if you can.



3. Spray the glass surface generously with application fluid. Then spray the adhesive side of the decal generously with application fluid.



4. Place the decal on to the glass. While the decal is wet, you can adjust position of the decal without damaging it.



5. Once in place, rub the decal onto the surface using a squeegee/hard card with firm strokes, to push out application fluid so that the decal adheres to the surface. Repeat this a few times until you remove most of the application fluid between the decal and the surface.

NOTE:

When you remove the application fluid, you are also pushing out the bubbles formed, achieving a smooth, bubble-free application.



6. Let the decal dry completely before you remove the transfer tape. Drying could take a few hours. Once dry, peel off the transfer tape. If the decal also peels off with the transfer tape, re-apply decal with squeegee and let it dry out before attempting to remove it.

7. Do a visual check. If you see small air or water bubbles, use your squeegee to push the air or water out.



CARE:

To clean, gently wipe decals with a damp cloth, making sure not to saturate the adhesive side with water.

Avoid using cleaners that contain alcohol, abrasives, citrus additives, or ammonias.